



- 1** Hour | Stunde
- 2** Minute | Minute
- 3** Stopwatch seconds | Stoppuhr Sekunden
- 4** Stopwatch minutes | Stoppuhr Minuten
- 5** 24-hour hand | 24-Stundenzeiger
- 6** Date | Datum
- 7** Normal position | Normalposition
- 8** 1st click | 1. Position
- 9** 2nd click | 2 Position
- A** Button A | Taste A | stop | Start
- B** Button B | Taste B | reset | Rücksetzung

**Battery | Batterie**

SR927W

**Movement | Uhrwerk**

Citizen-Miyota OS21

**Case thickness | Gehäusehöhe**

13,3 mm

**Circumference | Umfang**

Adjustable length | Größenverstellbar

**Weight | Gewicht**

128 g

**Glass | Glas**

Hardened mineral crystal | Mineralglas

**Backplate | Rückseite Gehäuse**

Metal, wood, glass | Metall, Holz, Glas

**Water resistance | Wassersäule**

Splash-proof | Spritzwasserfest

**Band width | Armbandbreite**

20 mm

**Band | Armband**

Metal, wood | Metall, Holz  
Screws | Schrauben

**Setting the time and date**

You can adjust the time by turning the crown in position two.

In position one you can adjust the date by turning the crown counterclockwise.\*

\*Don't set the date between 21:00 and 01:00 (the date may not change the next day).

**Uhrzeit und Datum einstellen**

Du kannst an der 2x herausgezogenen Krone durch Drehen die korrekte Uhrzeit einstellen. Bei 1x herausgezogener Krone kannst du durch Drehen gegen den Uhrzeigersinn das Datum einstellen.\*

\*Stelle das Datum nicht zwischen 21:00 und 01:00 Uhr ein (das Datum stellt sich sonst am nächsten Tag nicht richtig um).

**Instructions Band  
Anleitung Armband**

EN: [www.holz kern.com/en/faq/#size](http://www.holz kern.com/en/faq/#size)  
DE: [www.holz kern.com/de/faq/#size](http://www.holz kern.com/de/faq/#size)



**Accuracy/Month** ± 20 sec.  
**Genauigkeit/Monat** ± 20 Sek.



**Battery life** 2 Years  
**Batterie Lebensdauer** 2 Jahre