



- 1** Hour | Stunde
- 2** Minute | Minute
- 3** Second | Sekunde
- 4** 24-hour hand | 24-Stundenzeiger
- 5** Dual time 24-hour hand | Dual-Time 24-Stundenzeiger
- 6** Date | Datum
- 7** Normal position | Normalposition
- 8** 1st click | 1. Position
- 9** 2nd click | 2. Position

Battery | Batterie

SR621SW

Movement | Uhrwerk

Citizen - Miyota JP11

Circumference | Umfang

Adjustable length | Größenverstellbar

Case thickness | Gehäusehöhe

11,6 mm

Circumference | Umfang

Adjustable length | Größenverstellbar

Weight | Gewicht

132 g

Glass | Glas

Hardened mineral crystal | Mineralglas

Backplate | Rückseite Gehäuse

Metal | Metall

Water resistance | Wassersäule

5 atm

Band width | Armbandbreite

20 mm

Band | Armband

Wood, metal | Holz, Metall

Clasp pin | Spangenhstift

Setting the time and date

You can adjust the time by turning the crown in position two.

In position one you can adjust the date by turning the crown counterclockwise.*

*Don't set the date between 21:00 and 01:00 (the date may not change the next day).

Setting dual time

With the crown in normal position, you can correct the dual time with the buttons A and B by +/- 15 minutes.

Uhrzeit und Datum einstellen

Du kannst an der 2x herausgezogenen Krone durch Drehen die korrekte Uhrzeit einstellen. Bei 1x herausgezogener Krone kannst du durch Drehen im Uhrzeigersinn das Datum einstellen.*

*Stelle das Datum nicht zwischen 21:00 und 01:00 Uhr ein (das Datum stellt sich sonst am nächsten Tag nicht richtig um).

Dual-Time einstellen

In Normalposition kannst du die Dual-Time-Anzeige mit den Tasten A und B um +/- 15 Minuten korrigieren.

Instructions Band
Anleitung Armband

EN: www.holz kern.com/en/faq/#size

DE: www.holz kern.com/de/faq/#size



Accuracy/Month ± 20 sec.
Genauigkeit/Monat ± 20 Sek.



Battery life 2 Years
Batterie Lebensdauer 2 Jahre