



- 1** Hour | Stunde
- 2** Minute | Minute
- 3** Second | Sekunde
- 4** Stopwatch minutes | Stoppuhr Minuten
- 5** Stopwatch seconds | Stoppuhr Sekunden
- 6** 24-hour hand | 24-Stundenzeiger
- 7** Normal position | Normalposition
- 8** 1st click | 1. Position
- A** Button A | Taste A | stop | start
- B** Button B | Taste B | reset | Rücksetzung

**Battery | Batterie**

SR621SW

**Movement | Uhrwerk**

Citizen-Miyota JS20

**Case thickness | Gehäusehöhe**

11 mm

**Circumference | Umfang**

Adjustable length | Größenverstellbar

**Weight | Gewicht**

92 g

**Glass | Glas**

Hardened mineral crystal | Mineralglas

**Backplate | Rückseite Gehäuse**

Metal | Metall

**Water resistance | Wassersäule**

Splash-proof | Spritzwasserfest

**Band width | Armbandbreite**

18 mm

**Band | Armband**

Metal, wood | Metall, Holz

Pins | Steckstifte

**Setting the time**

You can adjust the time by turning the crown in position one.

**Uhrzeit einstellen**

Du kannst an der herausgezogenen Krone durch Drehen die korrekte Uhrzeit einstellen.

**Stopwatch**

This watch includes a stopwatch function which you can start and stop by pressing button A, and reset with button B.

You can adjust the second hand when using the stopwatch function by pulling the crown out one click (until the clock stops), then use button A to adjust the hand.

**Stoppuhr**

In diesem Modell ist eine Stoppuhr integriert, welche sich mit der Taste A starten und anhalten und mit der Taste B zurückstellen lässt.

Den Sekundenzeiger der Stoppuhr kannst du einstellen, indem du die Krone 1x herausziehst bis die Uhr komplett stillsteht. Nun kannst du mit der Taste A den Zeiger verstellen.

**Instructions Band**  
**Anleitung Armband**

 EN: [www.holzkern.com/en/faq/#size](http://www.holzkern.com/en/faq/#size)

 DE: [www.holzkern.com/de/faq/#size](http://www.holzkern.com/de/faq/#size)


**Accuracy/Month** ± 20 sec.  
**Genauigkeit/Monat** ± 20 Sek.



**Battery life** 2 Years  
**Batterie Lebensdauer** 2 Jahre